

Temp Wall Assembly Steps


Tools Required:

- Cordless Drill
- Drop Cloth
- 2 person for assembly


- 3 x Interlocking Duramax Temp Wall Panels
- 1 Top U Channel
- 2 Foot Plates
- 2 Standard Top/Bottom Clips
- 1 T-Style Clip
- 12 Stainless Steel Screws / Screw Caps

Follow the ABC Wall Assembly Steps illustrations below:



A) Lay Flat the wall panels on a clean non-porous floor or with a drop cloth.



Step 1




Step 2




Step 3

B) Insert the Top U-Channel on either side of the wall panels and drive in the screws to the predrilled holes as illustrated below. With Top U-Channel installed, one wall end will be flushed out, the other end is flushed in.




Step 1
Insert U-Channel



Step 2
Drive in screws

C) Mount the 2 Foot Plates at the bottom of the wall panels.



Step 1
Mount the 2 Snap-in Foot Plates




Fully Assembled Temp Wall

For Multiple
Configurations
Assembly Steps
See Next Page

Temp Wall Multiple Configurations Assembly Steps

Tools Required:
 • Cordless Drill
 • 2 person for assembly

- 2 Foot Plates
- 2 Standard Top/Bottom Clips
- 1 T-Style Clip
- 12 Stainless Steel Screws / Screw Caps



Mount with screws the Standard Clip to connect the top and bottom end-corner of Temp Walls.

Mount with screws the T-Style Clip to connect the top and bottom Mid Back Walls to one another and to other Mid Wall center divider.

